

ALMA MATER STUDIORUM – UNIVERSITÀ DI BOLOGNA

SCUOLA DI INGEGNERIA E ARCHITETTURA

DIPARTIMENTO DICAM in collaborazione con il Departamento de Química
FCT dell' UNIVERSIDADE NOVA DE LISBOA

CORSO DI LAUREA IN INGEGNERIA PER L'AMBIENTE E IL TERRITORIO

Curriculum internazionale Earth Resources Engineering

TESI DI LAUREA IN (tesi all'estero)

Biotechnology for the sustainable reclamation of contaminated lands and waters

***Implementation of Enhanced Biological Phosphorus Removal
(EBPR) wastewater treatment processes enriched
with different microbial communities***

CANDIDATO:

Giuseppe Alessio Costa

RELATORE:

Chiar.mo Prof. Lorenzo Bertin

CO-RELATORE:

Dott. Adrian Oehmen

Sessione II

Anno accademico 2013/2014

*A mia mamma
che ha permesso questo
nonostante tutto*

ACKNOWLEDGEMENTS

I really would like to thank the Universidade Nova de Lisboa and the Faculdade de Ciências e Tecnologia that have made this work possible: my first experience in a laboratory for 6 months in a wonderful city like Lisbon.

Thanks to my professor Bertin, my supervisor Dr. Adrian Oehmen, the coordinator of the department Maria Reis and especially Jorge and Monica that had the patience to teach me so many things in the laboratory, even in situations of pressure and in a demanding working environment that has made me grow in a topic that personally I have been always fascinated: the wastewater treatment processes.

Six months of erasmus that I will never forget in my life.

I thank also my family, my mum Anna and my sister Valentina, those people that have always believed in me and given to me all their support to face this *hard adventure* in ERE, the international faculty of environmental engineering in Bologna and given to me all the best advices while I was in Portugal and have visited me in fantastic days in which we have visited some beautiful cities in Portugal like Porto, Fatima, Coimbra, Cascais, Cabo de Roca and finally Lisbon in just a few days.

Thanks to Sergio, my Italian friend, that funny guy with which we spent a good time in the lab, without his jokes my permanence in the faculty would have been more monotonous and alone. Good conversations with him, difficult to have when you are abroad.

I thank also those wonderful Iranian guys that are Peymann, the first one met in Bologna, Amirreza, Mj, with their jokes they have made some days at university more funny.

Portineria Risorgimento staff too! Even with the part-time job they have allowed me to work on my thesis and supported me.

Last but not least, thanks to the wonderful colleagues of ERE: Eleonora, Paola, Andreina, Orsola. Despite all our trips in Europe, we have been good friends and colleagues of university, the lessons would have been more boring without their presence and also the last 2 years in Bologna!

I dedicate this thesis to my cousin's baby that has come to this world on 2nd December!

Index

ACKNOWLEDGEMENTS	1
List of tables	3
List of figures	4
Abstract (in italiano).....	6
I.Introduction.....	8
II. Sequencing Batch Reactors (SBR).....	10
III. Metabolism of Tetrasphaera and Accumulibacter	12
IV. Operation of the bioreactors	14
V. Analysis	20
V(a). Skalar analysis.....	21
V (b). TSS and VSS	25
V(c). TOC analysis.....	26
V(d). HPLC	27
V(e). FISH.....	29
V (f). Batch tests.....	33
VI. MATERIAL AND INSTRUMENTS.....	36
VII. RESULTS and discussion	41
VII (a). Skalar.....	41
VII (b). TOC.....	62
VII (c). VSS and TSS	66
VII (d). Batch tests	69
VII (e). FISH results.....	72
CONCLUSIONS.....	76
Bibliography	77
Appendix I. Accumulibacter TSS and VSS	78
Appendix II. Tetrasphaera TSS and VSS	79

List of tables

Table 1. Carbon source composition for Tetrasphaera	17
Table 2. Phosphorus source composition for Tetrasphaera	17
Table 3. Nitrate source composition for Tetrasphaera	17
Table 4. Carbon source composition for Accumulibacter	17
Table 5. Phosphorus source composition for Accumulibacter	17
Table 6. Nitrate source composition for Accumulibacter	18
Table 7. Micronutrients composition	18
Table 8. Accumulibacter phases duration	18
Table 9. Tetrasphaera phases duration	18
Table 10. Hybridization buffer preparation	31
Table 11. Washing buffer preparation	32
Table 12. Batch test preparation	35
Table 13. Anoxic and aerobic phosphorus uptake for Accumulibacter	50
Table 14. Anoxic and aerobic phosphorus uptake for Tetrasphaera	51
Table 15. Nitrate uptake for Accumulibacter	51
Table 16. Nitrate uptake for Tetrasphaera	51
Table 17. Ammonia anoxic uptake for Accumulibacter	51
Table 18. Ammonia anoxic uptake for Tetrasphaera	51
Table 19. General table of phosphorus analysis	55
Table 20. General table of ammonia analysis	55
Table 21. General table of nitrate analysis	56
Table 22. Nitrate analysis in batch tests (A, B) in duplicates for Acc	58
Table 23. Nitrate analysis in batch tests (A, B) in duplicates for Tet	60
Table 24. Test B for Tetrasphaera, analysis of nitrite	60
Table 25. Test B for Accumulibacter, analysis of nitrite	61
Table 26. Tetrasphaera TOC results	65

List of figures

Figure 1. Primary and secondary wastewater treatment, www.brighthub.com	9
Figure 2. Typical SBR stages, www.t-and-d-italy.com	10
Figure 3. Tetrasphaera bioreactor	14
Figure 4. Accumulibacter bioreactor	14
Figure 5. Sampling preparation	20
Figure 6. Skalar analyzer	21
Figure 7. Tetrasphaera filter after 550°C	25
Figure 8. Filtering the sample	25
Figure 9. TOC analyzer	26
Figure 10. HPLC column	27
Figure 11. Calibration curve for propionic acid	28
Figure 12. Calibration curve for acetic acid	29
Figure 13. FISH microscope	29
Figure 14. Batch system	33
Figure 15. Autoclave	36
Figure 16. Centrifuge	36
Figure 17. Dryer for VSS evaluation	37
Figure 18. Filter paper	37
Figure 19. Filtration system	37
Figure 20. 550°C oven	38
Figure 21. 100°C oven	38
Figure 22. Carbon source pump for Tetrasphaera	38
Figure 23. Pump for nitrate feed for Tetrasphaera, carbon and nitrate for Acc.	39
Figure 24. Pump for phosphorus feed to Tetrasphaera reactor	39
Figure 25. Pump for the phosphorus feeding to Acc. reactor	40
Figure 26. pH meter	40
Figure 27. Analysis of phosphorus in the whole cycle (Feb-May 2014)	41
Figure 28. Analysis of phosphorus in the whole cycle (May-June 2014)	42
Figure 29. Anoxic phosphorus uptake for Accumulibacter	42
Figure 30. Aerobic phosphorus uptake for Accumulibacter	42
Figure 31. Net phosphorus removal for the Acc. bioreactor in the whole analyzed period	43
Figure 32. Analysis of phosphorus in the whole cycle (13-19th Feb 2014)	44
Figure 33. Analysis of phosphorus in the whole cycle (Feb - May 2014)	44
Figure 34. Analysis of phosphorus in the whole cycle (May-June 2014)	44
Figure 35. Anoxic phosphorus uptake for Tetrasphaera	45
Figure 36. Aerobic phosphorus uptake for Tetrasphaera	45
Figure 37. Net phosphorus removal for the Tet. bioreactor in the whole analyzed period	46
Figure 38. Analysis of phosphorus in the whole cycle of Accumulibacter (Feb - June 2014)	47
Figure 39. Anoxic ammonia uptake for Accumulibacter	47
Figure 40. Analysis of ammonia in the whole cycle of Tetrasphaera (Feb - June 2014)	48
Figure 41. Anoxic ammonia uptake for Tetrasphaera	49
Figure 42. Nitrate uptake for Accumulibacter	50
Figure 43. Nitrate uptake for Tetrasphaera	50
Figure 44. Denitrification activity of Tetrasphaera in the whole analyzed period	52
Figure 45. Denitrification activity of Accumulibacter in the whole analyzed period	53
Figure 46. Anaerobic Tetrasphaera activity in the whole analyzed period	53
Figure 47. Anaerobic Accumulibacter activity in the whole analyzed period	54
Figure 48. Phosphorus analysis in batch tests (A,B,C) in duplicates	54

Figure 49. Ammonia analysis in batch tests (A,B,C) in duplicates	55
Figure 50. Nitrate analysis in batch tests (A,B,C) in duplicates	56
Figure 51. Phosphorus analysis in batch tests (A,B) in duplicates for Acc	57
Figure 52. Ammonia analysis in batch tests (A,B) in duplicates for Acc	57
Figure 53. Nitrate analysis in batch tests (A,B) in duplicates for Acc	58
Figure 54. Phosphorus analysis in batch tests (A,B) in duplicates for Tet	59
Figure 55. Ammonia analysis in batch tests (A,B) in duplicates for Tetrasphaera	59
Figure 56. Nitrate analysis in batch tests (A,B) in duplicates for Tetrasphaera	60
Figure 57. Nitrite analysis in batch tests (B) in duplicates for Tetrasphaera	61
Figure 58. Nitrite analysis in batch tests (B) in duplicates for Accumulibacter	61
Figure 59. Total organic carbon analysis (Feb-July 2014)	63
Figure 60. Total organic carbon (total removal) in the whole analyzed period	63
Figure 61. Total organic carbon (anaerobic removal) in the whole analyzed period	64
Figure 62. Total organic carbon ratio (anaerobic / total removal) in the whole analyzed period	64
Figure 63. Anaerobic Tetrasphaera activity in the whole analyzed period	65
Figure 64. TSS for Acc. in the whole analyzed period	66
Figure 65. VSS for Acc. in the whole analyzed period	67
Figure 66. TSS for Tet in the whole analyzed period	67
Figure 67. VSS for Tet in the whole analyzed period	68
Figure 68. VSS/TSS for Acc. in the whole analyzed period	68
Figure 69. VSS/TSS for Tetrasphaera in the whole analyzed period	69
Figure 70. N ₂ O analysis for Accumulibacter test B (4th June 2014)	69
Figure 71. N ₂ O analysis for Accumulibacter test B (4th June 2014), selected data	70
Figure 72. N ₂ O analysis for Accumulibacter test A (3rd June 2014)	70
Figure 73. N ₂ O analysis for Tetrasphaera test A (4th July 2014)	71
Figure 74. N ₂ O analysis for Tetrasphaera test B (6th July 2014)	71
Figure 75. N ₂ O analysis for Accumulibacter test C (5th June 2014)	72
Figure 76. FISH image with EUB and PAO probes, March 2014	73
Figure 77. FISH image with EUB and TET-174 probe, March 2014	73
Figure 78. FISH image with EUB and TET-266 probe, March 2014	74
Figure 79. FISH image with EUB and GAO probes, February 2014	74
Figure 80. FISH image with EUB and TET-654 probe, March 2014	75
Figure 81. FISH image with EUB and TET-174-266-654 probes, July 2014	75
Figure 82. FISH image with EUB and PAO probes, July 2014	75

Abstract (in italiano)

Il progetto ha l'obiettivo di studiare e favorire il processo di rimozione di fosforo da acque reflue in impianti dedicati al loro trattamento, sulla base del processo EBPR (*Enhanced Biological Phosphorus Removal*). Allo scopo, verranno utilizzati due bioreattori, arricchiti con microbatteri accumulatori di fosfato (PAO, *Polyphosphate Accumulating Organisms*) ed operanti come SBR (Sequencing Batch Reactors), alimentati ad intermittenza con 3 soluzioni, una di carbonio, una di fosforo e una di nitrato. I PAO utilizzando la sorsa di carbonio come COD, rimuovono sia il fosforo accumulato nella biomassa come polifosfato, che il nitrato, usato come accettore di elettroni. In una prima fase di acclimatizzazione si è cercato di individuare il rapporto tra la quantità di carbonio, fosforo e azoto che alimentati al bioreattore consentisse il corretto sviluppo e l'arricchimento della popolazione microbica di interesse (PAO) in equilibrio con altre popolazioni. Per contro, altri microrganismi, naturalmente presenti in un impianto di depurazione seppur in piccole quantità competono con i PAO e consumano importanti nutrienti per essi stessi, non portando alla rimozione del fosforo.

I principali competitori studiati in questo campo sono i cosiddetti GAO (*Glycogen Accumulating Bacteria*) soprattutto per il consumo di carbonio. Precedenti studi (Oehmen et al.) hanno dimostrato che una alimentazione di carbonio con 75 % di acetato e 25 % di propionato risulta più favorevole ai PAO, in questo modo la popolazione di GAO può essere ridotta, in concomitanza con un pH pari a 7.5.

Accumulibacter e *Tetrasphaera*, inoltre, sono in grado di usare come accettore di elettroni il nitrato. In questo modo si può ottenere la rimozione simultanea di nitrati e di fosfati. Ci sono, infatti, due tipi di PAO denitrificanti: un tipo usa il nitrato come accettore di elettroni e lo converte in nitrito e infine in azoto molecolare in una serie di passaggi metabolici. Un secondo tipo, invece, usa il nitrito che viene convertito in azoto molecolare. Quindi teoricamente tutti i nitrati e i nitriti vengono convertiti in azoto molecolare (N₂) che può essere emesso in atmosfera senza problema di sorta. Ma ci potrebbero essere delle reazioni con vie metaboliche alternative che potrebbero attivarsi e portare alla produzione finale di ossidi di azoto (NO_x), causando seri problemi se emessi in atmosfera.

Alcuni studi (Kampschreur et al., “*Nitrous oxide emission during wastewater treatment*”, *Water research*, 2009) confermano l'emissione di questo potente gas ad effetto serra da impianti di trattamento di acque reflue, soprattutto sottoforma di N₂O contribuendo al cambiamento climatico.

Lo scopo di questo lavoro è anche quello di controllare questa emissione e cercare di minimizzarla, sviluppato nella seconda fase del progetto. Per fare ciò si utilizzano delle speciali sonde che misurano la concentrazione di ossidi di azoto emessi dai bioreattori durante tutte le fasi (anaerobiche, anossiche e aerobiche) 24 ore su 24.

Il monitoraggio dei processi che verranno allestiti sarà di tipo sia chimico che biologico. Nel primo caso, verrà determinata la concentrazione di TOC (*Total Organic Carbon*) via analizzatore elementare, dei nutrienti target (fosfato, nitrato,

nitrito, azoto ammoniacale) via spettrofotometria, di carbonio in forma di acidi grassi volatili via HPLC (*High Performance Liquid Chromatography*), di solidi sospesi totali (TSS) e solidi sospesi volatili (VSS) via tecniche standard gravimetriche.

Nel secondo caso, l'impiego di tecnica FISH (*Fluorescence In Situ Hybridization*) sarà applicata per identificare qualitativamente la popolazione di microrganismi nei bioreattori.

I. Introduction

Wastewater treatment plants remove most pollutants from wastewater before being released to water bodies. In general, there are different steps of treatment: primary, secondary, optional tertiary and disinfection. In the primary treatment suspended and floated solids are taken away and sedimentation removes also suspended solids.

The secondary treatment, usually biological and called activated sludge process, is related to the removal of dissolved organic matter performed by microbes communities. A secondary sedimentation is done in this stage to remove more suspended solids. The tertiary treatment is used to remove additional pollutants, but it is generally quite expensive and not so widespread.

Sedimentation basins called clarifiers are used to allow the sludge sedimentation.

A disinfection typically with chlorine or UV is done before the discharge of the effluent in order to kill harmful organisms (disease bearing microorganisms or pathogens). A treatment of the waste sludge is also required before disposal.

The EBPR (Enhanced Biological Phosphorus Removal) is a type of secondary treatment in WWTP (WasteWater Treatment Plants), quite largely used in full-scale plants worldwide. The phosphorus present in aquatic systems in high amounts can cause the growth of algae and other photosynthetic microorganisms, such as cyanobacteria (more known as blue-green algae) and consequently the death of the fauna and flora. For this reason, recently this treatment has been developed to remove the phosphorus from wastewater and in this way to respect the regulation on P removal, nowadays getting more and more stringent.

The EBPR promotes the phosphorus removal without the use of chemical precipitants, being an environmentally friendly technique and is achieved through the activated sludge process recirculating the sludge and alternating anaerobic and aerobic conditions. Then, the waste sludge enriched in polyphosphate is removed. The recirculation and the use of not expensive sources make this process cost-effective and sustainable.

A specific biomass is used in order to remove the phosphorus, the so-called PAOs (Polyphosphate Accumulating Organisms) that accumulate the phosphorus in form of polyphosphate in their cells.

Some of these organisms, the so-called DPAO (Denitrifying Polyphosphate Accumulating Organisms) use as electron acceptor the nitrate or nitrite, contributing in this way also to the removal of these compounds from the wastewater. In theory, nitrate and nitrite are converted in molecular nitrogen that can be emitted in the atmosphere, but there could be side reactions carrying to the formation of nitrous oxides (NO_x), a real problem for their contribution to the greenhouse effect being 300 times stronger than CO_2 (IPCC, 2011). See paragraph *III. Metabolism of Tetrasphaera and Accumulibacter* for more details.

The aim of this project is to simulate in laboratory scale the EBPR, acclimatizing the biomass and enriching it, with the final objective of controlling the NO_x production.

In order to measure the removal of COD, phosphorus and nitrogen-derivate compounds, different analysis are performed: Skalar (measuring the concentration of phosphorus, nitrate, nitrite and ammonia), TOC (Total Organic Carbon, measuring the carbon consumption in Tetrasphaera), HPLC (High Performance Liquid Chromatography, measuring the carbon consumption in PAOs), total and volatile suspended solids according to standard methods APHA (American Public Health Association, TSS and VSS, measuring the biomass enrichment), FISH (Fluorescence In Situ Hybridization, measuring qualitatively the microorganism population).

Batch test are also performed to monitor the NO_x production. Some examples of results are reported in the paragraph VI. *Results and discussion*.

The experimental work is carried out at the *Faculdade de Ciências e Tecnologia* of *Universidade Nova de Lisboa* (FCT-UNL) from February to July 2014 with the supervision of Doctor Adrian Oehmen.




Figure1. Primary and secondary wastewater treatment, www.brighthub.com

II. Sequencing Batch Reactors (SBR)

The two bioreactors are operated as Sequencing Batch Reactors (SBRs), the fill and draw version of the activated sludge process. They are batch reactors operating on a number of cycles, each one including these phases: fill, react, settle, decant and idle. The time of each cycle can be manipulated in order to achieve biological nutrient removal alternating anoxic, anaerobic and aerobic. All the metabolic reactions and solid-liquid separation occur in one tank and in a specific time sequence. The exposure of the microorganisms to specific process conditions does not depend on the inflow coming inside the reactor, so this system is particularly appropriate in areas where the flow conditions of the wastewater is low or variable.

The SBR process operates within the following stages:

- 1) In the filling phase the influent is added to the biomass in aerated or non-aerated conditions
- 2) In the reacting phase the wastewater flow is limited, mixing the reactor
- 3) In the settling phase there is neither inflow nor outflow in quiescent conditions where there is the separation between the solid phase (biomass) and the liquid phase (supernatant)
- 4) In the drawing phase the clarified supernatant is discharged
- 5) The idling phase is a restricted period of time between draw and fill, particularly useful when there is more than one SBR.




Figure2. Typical SBR stages, <http://camix.com.vn/>

The advantages over conventional activated-sludge process are the following:

- 1) The treatment is effective independently on the influent flow rate
- 2) Ideal conditions for good activated-sludge settleability and less sludge production
- 3) Greater operational flexibility, using automatic controls and varying the duration of the phases
- 4) Minor operational cost, due to a more compact structure

III. Metabolism of Tetrasphaera and Accumulibacter

The Tetrasphaera microorganisms are polyphosphate accumulating organisms able to uptake aminoacids as carbon source, Accumulibacter are other PAOs, much more studied and known than Tetrasphaera, able to uptake organic carbon (volatile fatty acids, VFA) such as acetate and propionate. Both of them are largely responsible of phosphorus removal in wastewater treatment plants with activated sludge. They are mainly used in EBPR.

In the anaerobic phase the organic carbon is taken up and phosphorus is released from the cleavage (hydrolysis) of the polyphosphate compounds present in the wastewater. The energy needed to break the polyphosphate bonds comes from a polymeric compound known as PHA (PolyHydroxyAlkanoates) in the case of Acc. but still not known for the Tet. This polymer comes from the uptake of carbon (VFA, Volatile Fatty Acids such as acetate and propionate) that is accumulated inside the microorganism in the form of PHA. This is an energy source for the microorganism. In this phase also glycogen is degraded.

In the aerobic phase there is the phosphorus uptake, the PHA oxidation, so that the energy can be used and the glycogen regeneration. In this phase the biomass grows and proliferates.

In the aerobic phase the electron acceptor is oxygen whereas in the anaerobic is nitrate or nitrite. The fact that nitrogen can be used as electron acceptor in the anaerobic phase is an advantage because both nitrogen and phosphorus are removed in the same process.

There are two types of denitrifying PAOs (DPAOs): the Accumulibacter of type I uses nitrate as electron acceptor that is converted in nitrite and finally in molecular nitrogen (N_2). The Accumulibacter of type II uses nitrite as electron acceptor converting it in N_2 (Oehmen et al., 2010). So, in theory all nitrate and nitrite are converted in N_2 that can be emitted in the atmosphere without problems. But there could be some side reactions carrying to the formation of nitrogen oxides (NO_x) causing serious problems if emitted in the atmosphere. In fact this gas has a greenhouse effect 300 times stronger than CO_2 (IPCC, 2011). Studies (Kampschreur et al., 2009) confirm the emission of this greenhouse gas from wastewater treatment plant, especially in the form of N_2O contributing to climate change. The aim of this work is to monitor this emission and try to minimize it.

Below it is shown what happens in each phase, regarding the PHA, phosphate, biomass and glycogen.

PAOs

Anaerobic phase:

- VFAs uptake
- storage of PHA
- polyphosphate hydrolysis
- phosphorus release
- glycogen degradation

Aerobic/Anoxic phase:

- PHA degradation
- Phosphorus removal
- biomass growth
- glycogen production

GAOs

Anaerobic phase:

- VFAs uptake
- biomass growth
- storage of PHA
- glycogen degradation

Anaerobic/anoxic phase:

- PHA degradation
- glycogen production

IV. Operation of the bioreactors



Figure 3. Tetrasphaera bioreactor



Figure 4. Accumulibacter bioreactor

In the laboratory there are 2 bioreactors with mixed cultures, one enriched in Accumulibacter and one in Tetrasphaera, two kind of biomass known for being PAOs (polyphosphate accumulating organisms), studied by many authors (Carvalho et al., 2007; Oehmen et al., 2007), the first ones less known compared to the latter. The 2 bioreactors are operated as Sequencing Batch Reactors (SBRs) with intermittent feeding of carbon, ammonia, nitrate, phosphorus and other micronutrients in concentrations and operating conditions that favor the growth of PAOs, alternating anaerobic, anoxic and aerobic conditions in different cycles. The bioreactors are daily controlled, measuring online temperature, air content and pH. The needed sources are periodically prepared and sampling for the analysis is done every week.

Different carbon sources are added to each bioreactor as the main source of COD (Chemical Oxygen Demand), since the two kind of biomass (Accumulibacter and Tetrasphaera) have been shown to have different preferences regarding the carbon source: acetate for Accumulibacter and casinoamina for Tetrasphaera.

The aim of the wastewater treatment is the phosphorus removal but there are other microorganisms naturally present in the wastewater that can compete with the PAOs and can consume important nutrients for them, but not eventually removing the phosphorus.

The main microorganisms studied in this field competing with PAOs are the glycogen accumulating organisms, the so-called GAOs. The presence of these microorganisms should be minimized because they consume carbon but they do not remove phosphorus. PAOs and GAOs compete for the uptake of carbon and are naturally present in the sludge.

Previous studies (Oehmen et al.) have demonstrated that a feed of carbon based on

75 % of acetate and 25 % of propionate is more favorable to PAOs, being the best conditions for their proliferation. The population of GAOs can be consequently reduced. Acetate and propionate are naturally present in the sludge. A prefermentation on a plant scale can be the solution in order to obtain these quantities of carbon sources.

Also 50 % of acetate and 50 % of propionate is a good condition for PAOs proliferation, but the first option is chosen for the bioreactors described before.

In order to have stable conditions in the bioreactors, all the nutrients supplied have to be consumed, so the feed of the nutrients to the bioreactors is increased gradually.

Carbon source Tetrasphaera
150 ppm

Phosphorus source Tetrasphaera
30 ppm

Nitrogen source Tetrasphaera
25/02/2014 → 5 ppm (start of the anoxic phase)
28/02/2014 → 10 ppm
06/03/2014 → 20 ppm
13/03/2014 → 25 ppm
28/03/2014 → 30 ppm

Carbon source Accumulibacter
16/01/2014 → 100 ppm
29/01/2014 → 50 ppm
07/02/2014 → 100 ppm
17/02/2014 → 150 ppm

Phosphorus source Accumulibacter
30 ppm

Nitrogen source Accumulibacter
04/02/2014 → 10 ppm (start of the anoxic phase)
07/02/2014 → 5 ppm
17/02/2014 → 10 ppm
21/02/2014 → 20 ppm
28/02/2014 → 30 ppm
13/03/2014 → 25 ppm
28/03/2014 → 30 ppm
02/04/2014 → 25 ppm

The Tetrasphaera reactor was started 3 years ago with sludge from a wastewater treatment plant of Setubal (Portugal).

The Accumulibacter reactor is started in January 2014 with sludge coming from a wastewater treatment plant located in Beirolas (Portugal), near Lisbon.

Measures of carbon, nitrogen and phosphorus concentrations are taken (as described before, see paragraph *V(a)*. *Skalar analysis*) in order to see if these nutrients are consumed. If they are completely consumed, then their concentrations are increased, otherwise it is decreased or kept constant depending on how much is left in the bioreactor.

The phosphorus source has been kept at 30 ppm all over the acclimatization phase.

The nitrogen source for the Tetrasphaera reactor has been gradually increased up to 30 ppm, whereas more difficulties were encountered in finding the most appropriate concentration for the Accumulibacter reactor. The objective was to reach a concentration of 30 ppm like in the Tetrasphaera reactor, but the Accumulibacter reactor at this concentration was not stable, for this reason it has been decided to keep a concentration of 25 ppm. In fact, at 30 ppm the nitrate was not completely consumed, as the Skalar analysis confirmed.

The concentration of COD, nitrate and phosphate are very different from a full scale wastewater treatment plant, it is a synthetic medium fed to the bioreactor in laboratory scale. The aim is to see how the population of microorganisms behaves when present in high abundance, in order to better interpret the metabolism of these organisms without interference from the wide diversity of organisms normally present in wastewater treatment plants.

Carbon, phosphorus and nitrate are fed to the bioreactor enriched in Accumulibacter in these quantities: 250 ml/cycle, 750 ml/cycle and 50 ml/cycle respectively, 4 cycles/day are implemented, each 6 h long.

The initial COD fed is 50 ppm, during the acclimatization this will be increased up to 150 ppm.

The biomass present in the two bioreactors is approximately 1 l, the total volume of the bioreactors is therefore 2 l.

Regarding the bioreactor enriched in Tetrasphaera, 3 cycles/day are implemented, each 8 h long.

It is fed with 400 ml/cycle of carbon, 600 ml/cycle of phosphorus and 50 ml/cycle of nitrate.

In the next tables are shown the quantities of nutrients present in the different sources.

Carbon source (10 l)	
CasNa	7.9130 g
NH ₄ Cl	3.6980 g
MgSO ₄ .7H ₂ O	5.9380 g
CaCl ₂ .2H ₂ O	2.7600 g
ATU	0.0730 g
EDTA	0.1980 g
Micronutrients	19.8 ml

Table 1. Carbon source composition for Tetrasphaera

Phosphorus source (20 l)	
K ₂ HPO ₄	6.3160 g
KH ₂ PO ₄	3.8528 g

Table 2. Phosphorus source composition for Tetrasphaera

Nitrate source (2 l)		
40 ppm	NaNO ₃	19.4181 g
30 ppm	NaNO ₃	14.5640 g

Table 3. Nitrate source composition for Tetrasphaera

Carbon source (10 l)	
C ₂ H ₃ O ₂ Na.3H ₂ O	19.1303g
C ₃ H ₆ O ₂	2.0 ml
NH ₄ Cl	5.9167 g
MgSO ₄ .7H ₂ O	9.5000 g
CaCl ₂ .2H ₂ O	4.4167 g
ATU	0.1167 g
EDTA	0.3167 g
Micronutrients	31.7 ml

Table 4. Carbon source composition for Accumulibacter

Phosphorus source (25 l)	
K ₂ HPO ₄	6.3160 g
KH ₂ PO ₄	3.8528 g

Table 5. Phosphorus source composition for Accumulibacter

Nitrate source (2 l)		
40 ppm	NaNO ₃	19.4181 g
25 ppm	NaNO ₃	12.1360 g

Table 6. Nitrate source composition for Accumulibacter

Micronutrients (1 l)	
FeCl ₃ .6H ₂ O	1.50 g
H ₃ BO ₃	0.15 g
CuSO ₄ .5H ₂ O	0.03 g
KI	0.18 g
MnCl ₂ .4H ₂ O	0.12 g
Na ₂ MoO ₄ .2H ₂ O	0.06 g
ZnSO ₄ .7H ₂ O	0.12 g
CoCl ₂ .6H ₂ O	0.15 g

Table 7. Micronutrients composition

All the sources are sterilized in the autoclave at 121 °C and 1 bar for about 3 hours. The sterilization time itself lasts for 20 minutes, then the temperature inside the autoclave has to decrease until 90 °C before being opened for safety reasons.

Each cycle is composed of 3 phases: anaerobic, anoxic and aerobic (at the beginning of the acclimatization in the Tet. bioreactor the anoxic phase was not implemented). After the aerobic phase there is the settling of the biomass, in which the stirring device is switched off, the supernatant disposal in order not to overflow the bioreactor with continuous feeding and finally the so-called idle in which argon is supplied and the bioreactor is stirred in order to assure the next anaerobic phase. Here are shown the phases duration for both the bioreactors.

Acc.					
Sample	Anaerobic	Sample	Anoxic	Sample	Aerobic
0	0' (8:45-09:00)	5	After feed	9	4h30 (13:30)
1	5' (09:05)	6	2h09 (11:09)	10	5h15 (14:15)
2	30' (09:30)	7	2h45 (11:45)		
3	1h (10:00)	8	3h45 (12:45)		
4	1h45 (10:45)				

Table 8. Accumulibacter phases duration

TET					
Sample	Anaerobic	Sample	Anoxic	Sample	Aerobic
0	0' (08:45 -08:57)	5	After feed	9	6h (15:00)
1	0' (09:00)	6	3h24(12:24)	10	7h (16:00)
2	1h (10:00)	7	4h (13:00)		
3	2h (11:00)	8	5h (14:00)		
4	3h (12:00)				

Table 9. Tetrasphaera phases duration

The anaerobic phase is characterized by the feeding of carbon and phosphorus, with argon sparged to guarantee the absence of oxygen. In the anoxic phase only sodium nitrate is fed with argon for the same reason.

In the aerobic phase also air is supplied. The difference between the Tet. bioreactor and the Acc. one is that in the first one the carbon is fed continuously for 2 hours, whereas in the second one the carbon is fed in 5 minutes at the beginning of the anaerobic phase.

The pH is controlled in both the reactors with HCl (0.1 M), injecting it automatically when the pH overcomes the set value: in the Tet. it is controlled at 7.1, in the Acc. at 7.5.

A low pH favours the growth of GAOs, a too high pH causes the precipitation of phosphorus, a pH equal to 7.5 is ideal for PAOs proliferation (Oehmen, et al., 2007). The temperature is set at 20 °C controlled through a water bath for both the bioreactors and the air content is measured through a sensor. Usually it is 0 % in the anaerobic phase and around 72 % in the aerobic phase. Continuous graphs in real time are shown in the computer connected to the bioreactors, from which all parameters can be controlled and the different phases can be implemented automatically.

Regarding the Tetrasphaera reactor, in order to assure a SRT (Sludge Retention Time) of 19 days it is purged 105.26 ml from the bioreactor every day, whereas for the Accumulibacter reactor this volume is equal to 200 ml/day. The following formula is used to calculate the purge:

$$\frac{V_{purge}}{cycle} = \frac{V_{reactor}}{SRT \times \frac{n.cycles}{day}}$$

V. Analysis



Figure 5. Sampling preparation

Sampling from the bioreactors allows measuring the quantity of the main compounds involved in the metabolism of PAOs and GAOs. A sample is composed of a liquid phase, called supernatant, and a solid phase represented by the biomass that can be easily separated through a centrifugation.

Concerning the supernatant, samples from Acc. are analyzed in the HPLC (High Performance Liquid Chromatography) to measure the VFA, others from Tet. are analyzed in the TOC (Total Organic Carbon) to measure the carbon source. Tet. and Acc. are analyzed in a spectrophotometer (Skalar) to measure nitrite, nitrate, phosphorus and ammonia.

As the sampling procedure is concerned, 10 series of Eppendorfs are prepared 16 for each series for Tet. and 12 each for Acc. See tables 8 and 9, for more details. In each series of Eppendorfs, for Tet, 8 will be for supernatant, 2 of them to analyze the phosphorus and the nitrate in the Skalar and other 8 just for the biomass. For Acc. 6 Eppendorfs are for supernatant, 2 of them to analyze the phosphorus and the nitrate in the Skalar and other 6 just for the biomass. The samples with supernatant and those ones with biomass are stored into the freezer at -20°C . The samples for phosphorus and nitrate (supernatant) are stored into the fridge at $+4^{\circ}\text{C}$.

At the end of each phase (anaerobic, anoxic and aerobic) one sample is taken for FISH analysis, when necessary. This sample is stored into the fridge at 4°C .

At the end of the cycle (when the aerobic phase finishes) are taken one sample (5 ml tube) as Bruta, 2 for total phosphorus analysis (2 ml Eppendorf each) and another one (5 ml tube) for TSS/VSS. The samples of Bruta and TSS/VSS are stored into the fridge at $+4^{\circ}\text{C}$, whereas the total phosphorus samples are stored into the freezer at -20°C .

In addition, are taken samples from the carbon source, phosphorus and nitrate Schotts before the cycle starts or at the end. These samples are stored into the fridge at $+4^{\circ}\text{C}$. The sample at the end of the cycle is taken with particular attention because the settling phase starts some seconds later and the medium will be different. For this reason the sample is taken 1 or 2 minutes before the cycle finishes.

So, the samples from the bioreactor are taken at the times shown in the table 8 and 9 starting a timer just after the phosphorus feeding for *Tetrasphaera* finishes (08h57) at the beginning of the anaerobic phase. The phosphorus feeding for Tet lasts 3 minutes. Sampling after feeding means after the feeding of nitrate at the beginning of the anoxic phase. The nitrate feeding lasts 4 minutes and 26 seconds for both Tet and Acc.

The samples are taken from the bioreactor by means of a syringe directly connected to the bioreactor. Then, a centrifugation for 5 minutes at 10000 rpm is made for all the samples in order to separate the biomass (at the bottom) from the supernatant. After, the liquid supernatant can be taken from the Eppendorf through a micropipette, paying attention not to take any biomass, and put this supernatant into the empty Eppendorfs prepared before. The supernatant will be used to analyze the content of phosphorus and nitrate in the Skalar. The Eppendorfs obtained will be stored in the fridge or freezer as explained before.

V(a). Skalar analysis



Figure 6. Skalar analyzer

A spectrophotometer is used to measure nitrite, nitrate, phosphorus and ammonia in the supernatant. The instrument used is called Skalar and it is composed by an autosampler, a segmented flow analyzer and a computer from which the results can be seen.

The segmented flow analysis is a continuous flow method of wet chemistry analysis in which a stream of reagents and samples, segmented with air bubbles, is pumped through a manifold and treated in different processes such as mixing, heating or dialysis, before entering a flow cell to be detected. Air segmentation is used to prevent contamination.

Basically, the spectrophotometer measures the optical density of the sample, then it sends a signal to the interface depending on the optical density measured.

During the analysis some reagents are fed into the spectrophotometer. Reacting with the compounds mentioned above, they give products that are colored. For this reason it is called colorimetric method. If the resultant colour is white, there will be a small concentration of that compound and its peak in the resultant graph will be small, whereas if the colour is intense the concentration will be high and so the peak. The result is a graph with different peaks, in which a specific height corresponds to a specific concentration of the compound. The graph appears on the screen of the computer in real time. On the x-axis there is time, on the y-axis the response of the instrument.

The instrument works between 2 and 20 ppm, so the samples are diluted with MilliQ water reaching these quantities. The dilution is taken into account in the final results: setting the rate of dilution, the computer calculates the final concentration of the compound.

First of all, a stabilization of the instrument has to be reached with a constant baseline. Then, a calibration curve is obtained feeding standards from 4 to 20 ppm. Automatically the instrument assigns a specific concentration to different heights. The first sample is the “tracer” with 20 ppm, then there is a “wash” with only water. After, the different standards are put into the autosampler and again a standard of 20 ppm and a wash. The samples are then analyzed, each sample analysis lasting 3 minutes. After a sequence of samples there are always a drift (to correct the calibration curve) and a wash (to reset the instrument with null concentration).

In our case, the dilution of the sample for *Tetrasphaera* in which phosphate is measured is 4 times, whereas for *Accumulibacter* is 5 times. Measuring nitrite and nitrate, the samples are diluted less because they are present concentrations between 2 and 20 ppm, according to the instrument’s tolerability. On the contrary, the carbon is diluted very much because it is very concentrated, the rate of dilution being equal to 20 times. Also the phosphate source is measured, but it is just to control how much phosphorus is present in the medium, this datum is not considered in the successive data analysis.

At the end of the analysis the instrument has to be washed with water, then the baseline has to be stabilized.

A precise protocol is followed to use the Segmented Flow Analyzer.

- 1) reagents and standards are prepared and the reagent tubing is put into the reagent containers (appropriately labeled). The rinsing liquid supply tubing is placed on the sampler in distilled water
- 2) waste facilities are checked to be available
- 3) the pump is greased and then closed
- 4) the air bars are lifted by their rings and closed. Then the rings are released to place the bars square over the air tubing
- 5) the PC is switched on

- 6) The sampler is switched on and initialized
- 7) Interface, water bath, reactor control unit(s) and photometers are switched on.
- 8) The system is stabilized for 30 minutes
- 9) The software Flow Access is started. The pre-set temperature on the water bath and reactor control unit(s) is checked to be ok (40°C). The run is prepared with standards and samples appropriately diluted
- 10) The sampler is filled with the standards and the samples. The baseline is checked to be stable in real time and the run is started
- 11) When the run is finished the results are checked.

The autosampler provides the injection of the standards and the samples automatically.

In the chemistry unit the reagents are mixed with samples. The reaction mixtures are then detected. After detection the reaction mixture is sent to a waste facility. The measured signals are collected on a computer, where the data are processed.

The interface is needed for the automatic data acquisition and control of Continuous Flow analyzers. It is connected to the digital photometer, detectors, the sampler and the computer. The signals coming from the sampler and detectors are transferred to the computer.

The Skalar is used to determine the concentration of ammonia, nitrate, nitrite and phosphorus in the supernatant that should be free of biomass as much as possible.

The determination of ammonia is based on the modified Berthelot reaction. The ammonia is converted to monochloramine which reacts with salicylate to 5-aminosalicylate. After oxidation a green complex is formed. The absorption of this complex is measured at 660 nm.

The determination of nitrate and nitrite is based on the cadmium reaction method; after dialysis the sample is buffered at pH 8.2 and is passed through a column containing granulated copper-cadmium to reduce nitrate to nitrite. The nitrite is determined by reacting with sulfanilamide and N-(1-naphthyl) ethylenediaminedihydrochloride to form a highly coloured azo dye measured at 540 nm.

The determination of phosphate is based on the reaction between ammonium heptamolybdate and potassium antimony (III) oxide tartrate in an acidic medium with diluted solutions of phosphate to form an antimony-phosphomolybdate complex. This complex is then reduced to ascorbic acid intensively coloured in blue. This complex is measured at 880 nm.

Standards for ammonia

20 ppm N: dilute 2.0 ml stock solution 1000 ppm N to 100 ml with rinsing liquid sampler.

16 ppm N: dilute 1.6 ml stock solution 1000 ppm N to 100 ml with rinsing liquid sampler.

12 ppm N: dilute 1.2 ml stock solution 1000 ppm N to 100 ml with rinsing liquid sampler.

8 ppm N: dilute 0.8 ml stock solution 1000 ppm N to 100 ml with rinsing liquid sampler.

4 ppm N: dilute 0.4 ml stock solution 1000 ppm N to 100 ml with rinsing liquid sampler.

Standards for nitrate and nitrite

20 mg N/ liter: dilute 2.0 ml stock solution 1000 mg N/liter to 100 ml with rinsing liquid sampler.

16 mg N/liter: dilute 1.6 ml stock solution 1000 mg N/liter to 100 ml with rinsing liquid sampler.

12 mg N/liter: dilute 1.2 ml stock solution 1000 mg N/liter to 100 ml with rinsing liquid sampler.

8 mg N/liter: dilute 0.8 ml stock solution 1000 mg N/liter to 100 ml with rinsing liquid sampler.

4 mg N/liter: dilute 0.4 ml stock solution 1000 mg N/liter to 100 ml with rinsing liquid sampler.

Standards for phosphate

20 mg P/ liter: dilute 2.0 ml stock solution 1000 mg P/liter to 100 ml with rinsing liquid sampler.

16 mg P/liter: dilute 1.6 ml stock solution 1000 mg P/liter to 100 ml with rinsing liquid sampler.

12 mg P/liter: dilute 1.2 ml stock solution 1000 mg P/liter to 100 ml with rinsing liquid sampler.

8 mg P/liter: dilute 0.8 ml stock solution 1000 mg P/liter to 100 ml with rinsing liquid sampler.

4 mg P/liter: dilute 0.4 ml stock solution 1000 mg P/liter to 100 ml with rinsing liquid sampler.

V (b). TSS and VSS



Figure 7. Tetrasphaera filter after 550°C



Figure 8. Filtering the sample

The Total Suspended Solids and the Volatile Suspended Solids are measured according to this procedure, based on the standard method APHA (American Public Health Association).

- 1) glass fibers pretreatment in the oven before at 550 °C for 30 minutes and then at 100 °C for any time
- 2) weight the filters without biomass
- 3) filter the sample with the biomass
- 4) heat the filter with the biomass at 100 °C and weight
- 5) heat the filter with biomass at 550 °C and weight

The first heating at 100 °C of the filter is needed to vaporize the water and measure the TSS, whereas the second one at 550 °C is needed to volatilize any compound with low molecular weight and measure the VSS.

V(c). TOC analysis



Figure 9. TOC analyzer

The Total Organic Carbon is measured for Tetrasphaera. HPLC cannot be implemented because there are not columns for aminoacids, whereas there are for acetate and propionate for which liquid chromatography can be used. The instrument measures the total and the inorganic carbon, the organic carbon is then automatically calculated as the difference between the two. The program used is TOC V sample.

Preparation of the instrument:

- turn on the PC
- open the air valve
- turn on the instrument
- connect the instrument with the PC

Before starting the analysis, it has to be checked:

- pressure at 200 kPa
- level of water between low and high
- enough reagents (H_2O , HCl and H_3PO_4)
- change milli-Q water, the salts interfere in the results of inorganic carbon.

Preparation of the samples:

- centrifuge the samples for 3 minutes at 10000 rpm
- dilute 2 ml of sample with 8 ml of milli-Q water

When the TOC is ready, a green light will appear on the screen of the computer. Then, the instrument is washed with milli-Q water for 20 minutes. After the analysis there is a final wash of the instrument for 30-40 minutes, then the shut down (30 minutes).

The problem of this analysis is that there is not an autosampler, so each sample has to be placed into the instrument manually one by one. Each sample analysis lasts for around 10 minutes.

V(d). HPLC



Figure 10. HPLC column

The HPLC (High Performance Liquid Chromatography) is used to measure the consumption of carbon (that works as COD) in the Accumulibacter reactor.

The protocol followed is the following one:

- 1) Unfreeze the samples
- 2) Centrifuge the samples at 10000 rpm for 5 minutes
- 3) take 700 μ l of supernatant and put in the filter (it is a green filter inside the eppendorf)
- 4) centrifuge the sample at 10000 rpm for 5 minutes
- 5) wash the filter
- 6) take out 700 μ l of liquid from the eppendorf and put inside a vial with one drop of H_2SO_4 0.05 N
- 7) close the vial (the blue part on the side of the liquid)
- 8) store the sample in the freezer before the analysis

For the analysis, 9 different standards are prepared of 1000, 500, 250, 125, 62, 31, 15, 7 and 0 ppm with propionic acid and sodium acetate trihydrate in a solution of

sulfuric acid 0.01 N. The standard of 1000 ppm is prepared with 0.05 g of propionic acid and 0.1133 g of sodium acetate trihydrate in 50 ml H₂SO₄ 0.01N. The other standards are prepared with successive dilutions.

The standards are needed to calculate a calibration curve that put in relation the area of the pick in the HPLC analysis and the concentration of the compound of interest.

In the following graphs are shown typical calibration curve for propionic acid and sodium acetate trihydrate.

The compounds of interest are propionic acid and acetic acid fed to the bioreactor as carbon source. The real concentration of the 2 compounds are calculated with their real weight. Actually in the standards it is used sodium acetic acid trihydrate, so the concentration is corrected to the acetic acid with the following formula:

$$[\text{HAc}] = \frac{\text{mass}_{\text{NaAc}}}{50 \text{ ml}} \times \frac{\text{MW}_{\text{HAc}}}{\text{MW}_{\text{NaAc}}}$$

HAc = acetic acid

NaAc = sodium acetic acid

MW = molecular weight

V_{solution} (H₂SO₄ 0.01N) = 50 ml




Figure 11. Calibration curve for propionic acid




Figure12. Calibration curve for acetic acid

V(e). FISH



Figure 13. FISH microscope

The Fluorescence In Situ Hybridization is used to identify qualitatively the population of the microorganisms in the medium. The hybridization consists in stimulating the different bacteria with the light and some probes added to the sample allow to see the different colours. There are 4 probes for 4 different RNA of *Tetrasphaera* (TET1-226, TET2-174, TET2-892 and TET3-654), 1 probe for GAO (GAO mix), 1 for PAO (PAO mix), 1 for *Deffivococcus* and 1 for TFO (Tetrad Forming Organisms). The last 2 are a kind of glycogen accumulating organism. In addition, EUB mix is a probe needed to identify all bacteria, being a contrast color with the specific one of the particular bacteria.

In the results, the red colour represents the specific bacteria, whereas the green represents all bacteria. Overlapping the image in red and the other in green it will be obtained an image with yellow and green colours: the yellow representing the specific bacteria and the green again the whole population. This operation is done by

the software, snapshots of different images from the microscope can be taken, being a computer connected to the microscope.

The protocol describes different phases:

- sample fixation
- probes preparation
- samples application and dehydration
- probes hybridization
- washing
- mounting slides

Sample fixation

This phase slightly differs in the case of Gram + (Tetrasphaera) and Gram – (Accumulibacter).

Gram positive:

- add 1 ml of ethanol (98%) at -20 °C to 1 ml of sample.
- store at 4°C for 4-16 hours.
- centrifuge the sample at 10000 rpm for 3 minutes
- wash with 1 ml of PBS.
- centrifuge the sample at 10000 rpm for 3 minutes
- mix with 0.5 ml of PBS and 0.5 ml of ethanol
- store at -20 °C

Gram negative:

- add 1.5 ml of PFA (4%) to 0.5 ml of sample.
- store at 4°C for 1-3 hours.
- centrifuge the sample at 10000 rpm for 3 minutes
- wash with 1 ml of PBS.
- centrifuge the sample at 10000 rpm for 3 minutes
- wash with 1 ml of PBS
- centrifuge the sample at 10000 rpm for 3 minutes
- mix with 0.5 ml of PBS and 0.5 ml of ethanol
- store at -20 °C

Probes preparation

- Hydrate the lyophilized biomass with Milli-Q water
- froze and protect from light probes of 5 µl
- dilute probes to a final volume of 50 µl

Samples application and dehydration

- identify slides
- apply samples in each well (3 to 30 μL in each)
- air dry (preferentially) or at the oven at 46°C
- dehydrated in an ethanol series (3 min in each): 50%, 80% and 98% ethanol
(Use 50 ml Falcon tubes; max 2 slides per tube during dehydration)
- air dry or under compress air

Probes Hybridization

- with a tissue paper make a “bed” inside the 50 ml Falcon tube
- hybridization buffer is prepared in a 2 ml eppendorf tube (final concentrations - 0.9M NaCl, 0.01% SDS, 20 mmol Tris/HCl, pH 7.2)
 - 1) 360 μL NaCl 5M
 - 2) 40 μL TRIS-HCl 1M
 - 3) Formamide (see table 10 for amount)
 - 4) Milli-Q Water (see table 10 for amount)
 - 5) 2 μL SDS 10% (the last to mix because it can interact with NaCl and precipitate)
- apply 8 μL in each well. Do not touch the slide with the tip
- apply the rest of the buffer into the hybridization tube to keep the chamber in tube moist
- apply to each well 1 μL of probe (without touching the slide; gently mix the probes in the buffer)
- place the slide into the 50 ml Falcon tube in the horizontal position
- place the Falcon tube in the oven at 46°C for 1-2hours

Below is presented the table related to the preparation of the hybridization buffer.

Formamide amount (μL)	% Formamide on the well	H ₂ O MilliQ amount (μL)
0	0	1598
100	5	1498
200	10	1398
300	15	1298
400	20	1198
500	25	1098
600	30	998
700	35	898
800	40	798
900	45	698
1000	50	598

Table 10. Hybridization buffer preparation

Washing

- prepare wash buffer (total volume of 50 ml) in 50 ml Falcon tubes
 - 1) NaCl 5M (see table 11 for amount)
 - 2) 1ml of TRIS-HCl 1M
 - 3) EDTA 0.5M (see table 11 for amount)
 - 4) Raise the volume with Milli-Q H₂O up to 50 ml
 - 5) 50 µl SDS 10% (the last to mix)
- place wash buffer in the bath to reach 48°C before washing the slides
- wash slides: wash each slide with a Pasteur pipette and let the excess goes to a beaker. Place the slide into the washing buffer tube and into the bath at 48°C for 10-15 minutes.
- take the slides out and wash wells and slide (front and back) with Milli-Q water at 4°C
- dry the slide quickly to remove every single droplet from the slide to prevent probe dissociation (use compressed air)

Below is presented the table related to the preparation of the washing buffer.

% Formamide	NaCl amount (µl)	EDTA amount (µl)
0	9000	-
5	6300	-
10	4500	-
15	3180	-
20	2150	500
25	1490	500
30	1020	500
35	700	500
40	460	500
45	300	500
50	180	500

Table 11. Washing buffer preparation

Mounting slides

- apply a thin film of Vectashield to the dried slides
- place the cover slip and gently press it to force Vectashield to cover all wells
- clean the excess with a tissue paper
- apply nail polish to the board of the cover slip to prevent it to move away from the slide and prevent immersion oil to enter in the wells
- storage slides at -20°C protected from light.

V (f). Batch tests



Figure 14. Batch system

Samples are taken from the parent reactor (Acc. or Tet.) at the end of the anaerobic phase and the batch reactor is fed with this medium. In the batch reactor only the anoxic phase is implemented, injecting N_2O or others nitrate electron acceptors according to the table 9. A sensor measures online the N_2O production along the time. The sensor transmits a signal (mVolt) to the computer that is converted in concentration ($\mu\text{mol/l}$). The sensor is very sensitive to temperature, so this is kept constant all along the analysis. Also the pH is measured online, like the temperature. The temperature is set at $20\text{ }^\circ\text{C}$ and the pH at 7.1 for Tet. and 7.5 for Acc.

Before the analysis a calibration curve is obtained connecting signals and concentrations at different values. The computer shows in real time both the signal and the concentration.

Air is prevented from entering the reactor keeping it full of water, adding it inside the reactor through a syringe connected on the top of the reactor. Samples are taken through the same syringe.

Just the anoxic phase is analyzed because the de-nitrification process occurs just in this phase.

Different tests are performed injecting different nitrogen-derivate sources (nitrate, nitrite, N_2O) according to the table shown below. Also a phosphorus source is fed, but not carbon. In this way, the biomass is forced to use the internal carbon stored during the anaerobic phase.

The duration of the test is 1 hour and the samples are taken at time 0, 5, 10, 20, 30 and 60 seconds.

This is the protocol followed for each test:

1. Take out the solutions from the fridge
2. Calibrate the microsensors
3. Calibrate the pHmeter
4. Take the sludge at the end of the anaerobic phase from the parent reactor
5. Prepare 2 l of solution for washing sludge (100 ml macronutrients/1900ml water)
6. Wash the sludge 2 times, reaching a final volume of 450 ml.
7. Sparge the sludge with argon till the dissolved oxygen is zero.
8. Prepare the phosphorus solution, macro and micro nutrients
9. Insert the T meter with Teflon in the reactor
10. Insert the pH meter with Teflon
11. Dilute the biomass and place it inside the sealable reactor
12. Insert the N₂O microsensors with Teflon
13. start the stirrer (always at the same speed for all the experiments)
14. Check there are no leakages
15. Adjust the pH:
 - a. at 7.4 for dPAOs
 - b. at 7.0 for dTetrasphaera
16. Take a sample at time=0 before starting the experiment and samples from the medias
17. Add the electron acceptors needed
18. Take samples: 5, 10, 20, 30 and 60 minutes (close and open valves)
19. At minute 10 take 6 ml sample for m-RNA, freeze it with liquid nitrogen and store at -80°C
20. Centrifuge the samples at 10000 rpm for 5 minutes before separating the supernatant from the biomass
21. Filter the samples for Skalar, take the supernatant with a syringe with a needle and then take out the syringe and filter
22. Control pH by adding 0.1 M HCl or 0.5M NaOH
23. At the end of the experiment take 12 ml sample for solids and 5 ml for DNA and freeze at -20°C
24. Wash everything
25. Calibrate the microsensors
26. Put back the sludge into reactors:
 - a. 250 ml of dPAOs in total 450 ml after washing
 - b. 345 ml of dTET in total 450 ml after washing

Batch type	e ⁻ acceptor	Washing solution up to 2L (mL)		V of biomass	V of media to dilute (mL)		V of electron acceptor to add (mL)	
A	NO ₃ ⁻	Macro	100	225.00	P	4.5	NO ₃ ⁻	3.15
		Water	1900		Micro	3.57		
					Macro	11.25		
					Water	202.53		
					TOTAL VOLUME	450.00		
Batch type	e ⁻ acceptor	Washing solution up to 2L (mL)		V of biomass	V of media to dilute (mL)		V of electron acceptor to add (mL)	
B	NO ₂ ⁻	Macro	100	225.00	P	4.5	NO ₂ ⁻	3.15
		Water	1900		Micro	3.57		
					Macro	11.25		
					Water	202.53		
					TOTAL VOLUME	450.00		
Batch type	e ⁻ acceptor	Washing solution up to 2L (mL)		V of biomass	V of media to dilute (mL)		V of electron acceptor to add (mL)	
C	N ₂ O	Macro	100	225.00	P	4.5	N ₂ O	8.25
		Water	1900		Micro	3.57		
					Macro	11.25		
					Water	197.44		
					TOTAL VOLUME	450.00		

Table 12. Batch test preparation

VI. MATERIAL AND INSTRUMENTS

An autoclave Uniclave77 AJC is used to sterilize the carbon medium. After the preparation of the source in a Schott, this is firmly closed, the plastic parts are covered with aluminium foil and then is placed carefully inside the autoclave, where a resistance is covered with water. Then the autoclave is firmly closed and switched on.

The temperature increases up to 121 °C and the pressure until 2 bar, at 121 °C there is the sterilization for 20 minutes, then the temperature decreases again. When the temperature reaches 90 °C and the pressure 1 bar, the autoclave can be opened, paying attention to the heat coming out.



Figure 15. Autoclave

A centrifuge VWR Microstar 17 is used to separate the supernatant from the biomass during the sampling and in the preparation of the samples for HPLC analysis. This is run at 10000 rpm for 5 minutes.



Figure 16. Centrifuge

A dryer is used for VSS evaluation, after the filter is taken out from the oven at 550 °C. This is needed to take out the humidity from the filter. Below it is shown the type of filters used in this analysis, a Reeve Angel filter paper.



Figure 17. Dryer for VSS evaluation



Figure 18. Filter paper

A filtration system KNF Neubergeris used to filter the sample in the TSS-VSS evaluation.



Figure 19. Filtration system

An oven Nabertherm is used to put the filtered sample at 550 °C. Below it is shown also the oven at 100 °C (Mettmert) .



Figure 20. 550°C oven



Figure 21. 100°C oven

For Tetrasphaera reactor a pump Watson-Marlow sci 400 is used to pump the carbon source into the reactor. The flow is equal to 3.33 ml/min. This pump is calibrated each time the medium is changed.



Figure 22. Carbon source pump for Tetrasphaera

A pump Watson-Marlow 502s is used to feed the nitrate source to the Tetrasphaera reactor, the carbon and the nitrate sources to the Acc. reactor. The flows in order are 0.18 ml/s for both the nitrate sources and 0.83 ml/s for the carbon source in the Acc. reactor. All of them are pulses.



Figure 23. Pump for nitrate feed for Tetrasphaera, carbon and nitrate for Acc.

A pump SP311 VelpScientifica is used to feed the phosphorus medium to the Tetrasphaera reactor. The flow is 200 ml/min.



Figure24. Pump for phosphorus feed to Tetrasphaera reactor

A pump Watson Marlow sci 323 is used to feed the phosphorus source to the PAO reactor. The pulse in this case is 2.5 ml/s.



Figure 25. Pump for the phosphorus feeding to Acc. reactor

A pH meter Orion Dual Star pH ISE Benchtop is used to measure the pH of the solutions, in specific of the carbon sources and of the standards prepared for Skalar and HPLC analysis.



Figure 26. pH meter

VII. RESULTS and discussion

The period analyzed is from February to July 2014. The batch tests started in June (reported until July).

VII (a). Skalar

The Skalar tests are performed once a week, generally the day after the sampling. The more the reactors are acclimatized, the less samples are taken. In fact, in the last months (June-July) just 4 samples were taken and the sampling is less frequent. From February to June 10 samples are taken from both *Accumulibacter* and *Tetrasphaera* reactors according to the timetable shown in tables 8 and 9. See paragraph V. *Analysis* for more details about the sampling procedure.

The reactors work in continuous with the cycles described in paragraph IV. *Operation of the bioreactors.*

Regarding the phosphorus, it is observed the typical trend of release and uptake respectively in anaerobic and anoxic/aerobic conditions.

In the anaerobic phase the phosphorus is released because of the hydrolysis of polyphosphate and the consumption of ATP in order to uptake the VFAs (Volatile Fatty Acids).

In the anoxic and aerobic phase, it can be observed the uptake of phosphorus in higher quantities than those ones released in the anaerobic phase. In addition, sludge enriched in polyphosphate is discharged: the overall balance is a successful uptake of phosphorus by the microorganisms and its decrease in the supernatant, so the EBPR works well. See table 13 and 14 for more details.




Figure 27. Analysis of phosphorus in the whole cycle (Feb-May 2014)




Figure 28. Analysis of phosphorus in the whole cycle (May-June 2014)

In the following graphs are shown the trends of anoxic and aerobic phosphorus uptake for Accumulibacter.

The uptake is up to 42 % and 58 % respectively. The anoxic one is in the range between 0.13 and 1.95 P-mmol/l, whereas the aerobic between 0.14 and 2.26 P-mmol/l for Acc. On average the anoxic is 0.79 whereas the aerobic 1.35 P-mmol/l.




Figure 29. Anoxic phosphorus uptake for Accumulibacter




Figure 30. Aerobic phosphorus uptake for Accumulibacter

It is also calculated the net phosphorus removal, being simply the difference between the uptake and the release. The percentage is calculated again with respect to the end of the anaerobic phase. Below it is shown a graph with the percentage of net phosphorus removal all along the analyzed period. It can be observed that there is an increasing trend.




Figure 31. Net phosphorus removal for the Acc. bioreactor in the whole analyzed period

In the following graphs are shown the concentration of phosphorus in the whole cycle from February to June 2014 and the trends of anoxic and aerobic phosphorus uptake for Tetrasphaera.

The uptake is up to 15 % and 73 % respectively. The anoxic one is up to 0.34 P-mmol/l, whereas the aerobic uptake reaches values of 1.51 P-mmol/l. On average the anoxic is 0.14 whereas the aerobic 0.53 P-mmol/l.




Figure 32. Analysis of phosphorus in the whole cycle (13-19th Feb 2014)




Figure 33. Analysis of phosphorus in the whole cycle (Feb - May 2014)




Figure 34. Analysis of phosphorus in the whole cycle (May-June 2014)

Here are shown the uptake relatively to Tetrasphaera reactor starting from March 2014, because before it was not implemented an anoxic phase in the Tetrasphaera reactor.

In general, there is a decreasing trend of phosphorus uptake in both reactors.




Figure 35. Anoxic phosphorus uptake for Tetrasphaera




Figure 36. Aerobic phosphorus uptake for Tetrasphaera

In the graph below it is shown the net phosphorus removal regarding the Tet. reactor. It can be observed that there are negative values of removal, it means that occasionally there have been also net phosphorus release with increase phosphorus concentration inside the bioreactor at the end of the cycle. Also the removal is quite low.




Figure 37. Net phosphorus removal for the Tet. bioreactor in the whole analyzed period

In the ammonia analysis the trends are slightly different for Tetrasphaera and Accumulibacter reactor.

In the Tet. reactor, in the anaerobic phase it can be observed an increase of ammonia in the first 2 hours: this is because of the ammonia feeding with the carbon source that lasts exactly 2 hours. In the anoxic/aerobic phase the ammonia slightly decreases because it is used for biomass growth.

In the Acc. reactor, there is the same increase as Tet. but this lasts for just some minutes (the carbon source feeding time lasts 5 minutes).

Then again a decrease due to the uptake of ammonia used for biomass growth.

It can be affirmed that ammonia is not removed for nitrification, since this process is inhibited by the addition of ATU in the media.




Figure 38. Analysis of phosphorus in the whole cycle of Accumulibacter (Feb - June 2014)

The anoxic uptake of ammonia is on average 0.24 N-mmol/l with a percentage related to the end of the anaerobic phase of 8.52 %. In the first months of the analysis there was an increasing trend of the ammonia uptake up to 0.53 N-mmol/l and 18 %. In the last days there has been a high decrease of uptake due to some problems with the reactor. See table 17 for more details.




Figure 39. Anoxic ammonia uptake for Accumulibacter




Figure 40. Analysis of ammonia in the whole cycle of Tetrasphaera (Feb - June 2014)

The anoxic uptake of ammonia is on average 0.15 N-mmol/l with a percentage related to the end of the anaerobic phase of 3.28 %. It can be observed an increase in the first months up to 0.28 N-mmol/l and a percentage of 5.65 % then a decrease. There were days in which it was not verified any ammonia uptake. See table 18 for more details.




Figure 41. Anoxic ammonia uptake for Tetrasphaera

In the nitrite analysis it can be verified that it is completely consumed all along the cycle from anaerobic to aerobic conditions. This is in agreement with the metabolism of denitrifying PAOs in which there is the conversion of nitrate to nitrite and finally molecular nitrogen. This last step is so fast that the nitrite concentration is zero.

Concerning the nitrate analysis, it can be seen a general consumption of this compound, but with higher concentrations at the beginning of the anoxic phase. A graph below shows also an increasing consumption of nitrate all along the analyzed period.

These consumptions are due to the denitrifying activity of PAOs that use nitrate as electron acceptor to remove the phosphorus.

In these analysis only the anoxic and aerobic phases are taken into consideration because the nitrate/nitrite is fed just in the anoxic phase and it is consumed until the aerobic phase.

For both reactors there is an increase of nitrate consumption all along the whole analysis.




Figure 42. Nitrate uptake for Accumulibacter




Figure 43. Nitrate uptake for Tetrasphaera

In the following tables are presented the general results for all the analysis.

P Accumulibacter		min	max	average
Anox. uptake	P-mmol/l	0.13	1.95	0.79
	%	5.87	42.18	23.21
Aerob. uptake	P-mmol/l	0.14	2.26	1.35
	%	5.22	58.47	39.91
Anaer. release	P-mmol/l	0.25	3.67	2.03
	%	8.98	83.16	56.59
TOT. UPTAKE	P-mmol/l	0.30	3.35	2.13
	%	11.10	84.20	63.12
TOT. RELEASE	P-mmol/l	0.25	3.67	2.03
	%	8.98	83.16	56.59
NET P REMOVAL	P-mmol/l	-0.59	1.72	0.22
	%	-31.59	62.29	7.17

Table 13. Anoxic and aerobic phosphorus uptake for Accumulibacter

P Tetrasphaera		min	max	average
Anox. uptake	P-mmol/l	0.00	0.34	0.14
	%	0.00	15.47	6.08
Aerob. uptake	P-mmol/l	0.07	1.51	0.53
	%	1.51	73.01	23.80
Anaerob. release	P-mmol/l	0.00	2.03	1.16
	%	0.00	69.42	47.67
TOT. UPTAKE	P-mmol/l	0.16	1.62	0.67
	%	4.29	78.66	29.71
TOT. RELEASE	P-mmol/l	0.00	2.03	1.16
	%	0.00	69.42	47.67
NET P REMOVAL	P-mmol/l	-1.82	0.39	-0.46
	%	-41.27	18.83	-16.90

Table 14. Anoxic and aerobic phosphorus uptake for Tetrasphaera

NO ₃ Acc		min	max	average
uptake	ppm	1.33	14.30	7.78
	%	34.64	100.00	73.68

Table 15. Nitrate uptake for Accumulibacter

NO ₃ Tet		min	max	average
uptake	ppm	2.08	18.42	9.66
	%	3.67	100.00	80.28

Table 16. Nitrate uptake for Tetrasphaera

NH ₃ Acc		min	max	average
Anox.uptake	N-mmol/l	-0.08	0.53	0.24
	%	-3.76	18.41	8.52

Table 17. Ammonia anoxic uptake for Accumulibacter

NH ₃ Tet		min	max	average
Anox.uptake	N-mmol/l	0.03	0.28	0.15
	%	0.71	5.65	3.28

Table 18. Ammonia anoxic uptake for Tetrasphaera

In the calculations all the percentages are referred to the value of concentration at the end of the anaerobic phase, 3 hours for Tetrasphaera and 1 hour and 45 minutes for Accumulibacter, and are calculated as:

$$\text{percentage} = \frac{\text{uptake/release}}{\text{anaerobicconc}} \times 100$$

The anaerobic uptake or release is calculated between the concentration at 0 hours (the first sample before the carbon feeding) and at 3 hours for Tetrasphaera.

The anoxic uptake or release is calculated between the concentration at 3 hours and at 5 hours for Tetrasphaera.

The aerobic uptake or release is calculated between the concentration at 5 hours and at 7 hours for Tetrasphaera.

Regarding the Accumulibacter, the anaerobic uptake or release is calculated between the concentration at 0 hours (the first sample before the carbon feeding) and at 1 hour and 45 minutes. The anoxic between 1 hour and 45 minutes and 3 hours and 45 minutes and the aerobic between 3 hours and 45 minutes and 5 hours and 15 minutes.

In the following graphs are presented the ratio (phosphorus uptake / nitrate uptake) and (phosphorus release / carbon uptake). The first is related to the anoxic activity of the microorganisms and its de-nitrification, the second with their anaerobic activity.

The de-nitrification activity for both reactors is rather low, being the phosphorus uptake low as compared to the nitrate uptake. Unfortunately, this activity has decreased in the last analysis. Anyway there are values of P uptake/NO₃ uptake up to 3.89 for Acc. and 0.64 for Tet. In the graph of Tet. it is not considered the first period of acclimatization in which there was not implemented the anoxic phase.




Figure44. Denitrification activity of Tetrasphaera in the whole analyzed period




Figure 45. Denitrification activity of Accumulibacter in the whole analyzed period

Also the anaerobic activity is presented in figures 46 and 47, being the ratio P release/C uptake between 0.10 and 0.65 for Tetrasphaera and up to 0.60 for Accumulibacter.

Regarding the Acc. reactor, the carbon uptake used is the theoretical one, because there were problems with the HPLC analysis at that time. So, it is considered that 75 % of COD (150 ppm) is acetate and 25 % is propionate, then it is taken the sum of the 2 compounds in C-mmol/l. In the Acc. Bioreactor there is 9.38 C-mmol/l of acetate and 3.13 C-mmol/l of propionate, considering the final value of 6.25 C-mmol/l, summing up the concentrations of the two volatile fatty acids and dividing it by 2, since it is added only 1 l of carbon source in the Accumulibacter bioreactor.




Figure 46. Anaerobic Tetrasphaera activity in the whole analyzed period




Figure 47. Anaerobic Accumulibacter activity in the whole analyzed period

Skalar analyses are performed also for batch tests. In the following graphs are shown the main results. These analyses were done in June 2014. The letters A,B,C refers to the kind of batch test performed, see table 12 in paragraph V (f) *Batch tests*. The analysis are done in duplicates (A, A2, B, B1, C, C1), it means that the same sample is analyzed twice. It can be seen that the results of the duplicates are comparable.




Figure 48. Phosphorus analysis in batch tests (A,B,C) in duplicates

In these tests the phosphorus is consumed up to 5.31 %, as it can be seen from the table below.

	A	A2	B	B1	C	C1
Date	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014
Time (min)	[P]	[P]	[P]	[P]	[P]	[P]
	P-mmol/l	P-mmol/l	P-mmol/l	P-mmol/l	P-mmol/l	P-mmol/l
0	2.73	2.57	5.40	5.32	3.70	3.76
5	2.73	2.66	5.31	5.33	3.60	3.63
10	2.71	2.59	5.39	5.40	3.62	3.61
20	2.73	2.57	5.33	5.40	3.63	3.68
30	2.68	2.57	5.38	5.36	3.71	3.68
60	2.59	2.50	5.35	5.30	3.66	3.65
cons (P-mmol/l)	0.15	0.07	0.05	0.02	0.05	0.11
cons (%)	5.31	2.71	0.87	0.36	1.27	2.94

Table 19. General table of phosphorus analysis




Figure 49. Ammonia analysis in batch tests (A,B,C) in duplicates

Also here there is a decrease of the concentration of ammonia, with consumptions up to 6.64 %. Below a table is reported with the data and consumptions. In the test A the concentration of ammonia is almost constant.

	A	A2	B	B1	C	C1
Date	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014
Time (min)	[NH ₃]	[NH ₃]	[NH ₃]	[NH ₃]	[NH ₃]	[NH ₃]
	N-mmol/l	N-mmol/l	N-mmol/l	N-mmol/l	N-mmol/l	N-mmol/l
0	1.21	1.13	1.29	1.24	1.25	1.29
5	1.24	1.16	1.27	1.25	1.23	1.24
10	1.25	1.14	1.26	1.24	1.24	1.25
20	1.24	0.79	1.27	1.25	1.23	1.23
30	1.23	1.12	1.26	1.24	1.22	1.23
60	1.22	1.11	1.26	1.23	1.22	1.20
cons (N-mmol/l)	-0.01	0.02	0.03	0.01	0.04	0.09
cons (%)	-0.77	1.52	2.44	0.52	2.91	6.64

Table 20. General table of ammonia analysis




Figure 50. Nitrate analysis in batch tests (A,B,C) in duplicates

Here is also the consumption of nitrate, much higher than those ones for phosphorus and ammonia. Indeed, the consumption reaches values of 85 %. The last test of type C shows the absence of this compound. Below the table with concentrations and consumptions.

	A	A2	B	B1	C	C1
Date	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014	20/06/2014
Time	[NO ₃]	[NO ₃]	[NO ₃]	[NO ₃]	[NO ₃]	[NO ₃]
(min)	ppm	ppm	ppm	ppm	ppm	ppm
0	0.00	0.00	0.00	0.00	0.00	0.00
5	92.84	91.15	25.06	28.83	0.00	0.00
10	20.17	18.07	13.76	13.29	0.00	0.00
20	17.88	16.50	12.30	10.86	0.00	0.00
30	16.99	16.14	11.18	10.26	0.00	0.00
60	13.76	14.69	9.41	8.96	0.00	0.00
cons (ppm)	79.08	76.46	15.65	19.87	0.00	0.00
cons (%)	85.18	83.88	62.45	68.92	0.00	0.00

Table 21. General table of nitrate analysis

In other Skalar analysis, it is also measured the nitrite concentration, but like in the previous analysis there is no trace of this compound, completely and very rapidly converted in molecular nitrogen.

In the following graphs and tables are shown other results of samples taken from batch tests of July 2014. In general there are low consumption of both phosphorus and ammonia for both reactors. The nitrate consumption is much higher with percentages up to 72 % for Tetrasphaera and 37 % for Accumulibacter.




Figure51. Phosphorus analysis in batch tests (A,B) in duplicates for Acc.




Figure 52. Ammonia analysis in batch tests (A,B) in duplicates for Acc.




Figure 53. Nitrate analysis in batch tests (A,B) in duplicates for Acc.

	A	A2	B	B1
Date	03/07/2014			
Time	[NO₃]	[NO₃]	[NO₃]	[NO₃]
(min)	ppm	ppm	ppm	ppm
0	0.68	0.66	0.57	1.09
5	21.69	19.08	25.20	23.49
10	18.40	17.91	21.03	20.10
20	16.71	14.95	18.49	18.57
30	15.21	14.49	17.38	17.34
60	13.87	12.27	15.83	14.90
cons (ppm)	7.82	6.81	9.37	8.59
cons (%)	36.05	35.69	37.18	36.57

Table 22. Nitrate analysis in batch tests (A,B) in duplicates for Acc.




Figure 54. Phosphorus analysis in batch tests (A,B) in duplicates for Tet




Figure 55. Ammonia analysis in batch tests (A,B) in duplicates for Tetrasphaera




Figure 56. Nitrate analysis in batch tests (A,B) in duplicates for Tetrasphaera

	A	A2	B	B1
Date	03/07/2014			
Time	[NO₃]	[NO₃]	[NO₃]	[NO₃]
(min)	ppm	ppm	ppm	ppm
0	0.68	0.66	0.57	1.09
5	21.69	19.08	25.20	23.49
10	18.40	17.91	21.03	20.10
20	16.71	14.95	18.49	18.57
30	15.21	14.49	17.38	17.34
60	13.87	12.27	15.83	14.90
cons (ppm)	7.82	6.81	9.37	8.59
cons (%)	36.05	35.69	37.18	36.57

Table 23. Nitrate analysis in batch tests (A,B) in duplicates for Tet

In the test B of both Accumulibacter and Tetrasphaera there is nitrite consumption that is fed in the reactor. Its consumption is up to 79 % for Tetrasphaera and 42 % for Accumulibacter. It can be observed that the nitrite consumption is greater in the Tet. reactor compared to the Acc. one.

	B	B1
Date	03/07/2014	
Time	[NO₂]	
(min)	ppm	ppm
0	0.00	0.00
5	25.16	26.28
10	15.50	13.18
20	13.01	15.68
30	11.28	10.90
60	6.73	5.59
cons (mmol/l)	18.43	20.69
cons (%)	73.25	78.73

Table 24. Test B for Tetrasphaera, analysis of nitrite

	B	B1
Date	03/07/2014	
Time	[NO ₂]	
(min)	ppm	ppm
0	0.00	0.00
5	25.16	26.28
10	15.50	13.18
20	13.01	15.68
30	11.28	10.90
60	6.73	5.59
cons (mmol/l)	18.43	20.69
cons (%)	73.25	78.73

Table 25. Test B for Accumulibacter, analysis of nitrite

Here are reported the related graphs.




Figure 57. Nitrite analysis in batch tests (B) in duplicates for Tetrasphaera




Figure 58. Nitrite analysis in batch tests (B) in duplicates for Accumulibacter

VII (b). TOC

The TOC analysis is performed once a week. The samples are taken according to the procedure described in the paragraph V. *Analysis*. See paragraph V (c). *TOC analysis* for more details about the measurements. The execution time depends on the number of the samples, being 10 minutes the analyzing time of 1 sample. There is no autosampler, so the samples are manually put in the sampler.

In the analysis of total organic carbon there is the general trend of increase in the first 2 hours and then a decrease. This is due to the fact the carbon is fed in the Tetrasphaera reactor in the first 2 hours, then the carbon is taken up as a nutrient in the form of aminoacids. This means also a decrease of COD in the treated water.

The following formulas are used to calculate the initial value of TOC present at the beginning of anaerobic phase, the anaerobic consumption of TOC and its consumption in the whole cycle.

$$\text{initial TOC} = \frac{(0.4 \text{ l} \times \text{TOC}_{\text{source}}) + (1 \text{ l} \times \text{TOC}_{\text{oh}})}{2 \text{ l}}$$

$$\text{Anaerobic TOC consumption} = \text{initial TOC} - \text{TOC}_{3\text{h}}$$

$$\text{Total TOC consumption} = \text{initial TOC} - \text{TOC}_{7\text{h}}$$

In all these calculations, it is taken into consideration that there is a gradual feed of carbon, so the volume gradually increases with the carbon feeding in the first 2 hours up to 2 l. The volume of the carbon feed is 0.4 l.

Below it is shown the trend in the whole analyzed period. The trend is very similar for all the days analyzed except from some datas out of range. It can be observed the initial feeding of carbon up to 2 hours, then a decrease of carbon concentration until the end of the aerobic phase.




Figure 59. Total organic carbon analysis (Feb-July 2014)

Below are shown graphs regarding the total and anaerobic carbon removal and their ratio.




Figure 60. Total organic carbon (total removal) in the whole analyzed period




Figure 61. Total organic carbon (anaerobic removal) in the whole analyzed period




Figure 62. Total organic carbon ratio (anaerobic / total removal) in the whole analyzed period

It can be observed an anaerobic TOC removal from 64 % in the first months up to 80 % in the last period analysed. The TOC removal in the whole cycle is even better with values between 75 % and 87 %.

A graph with the ratio anaerobic/total removal shows this general increase in the carbon removal, with values up to 0.94.

The Tetrasphaera anaerobic activity shows a high release of phosphorus compared to the uptake in the anoxic and anaerobic phases. In the figure 61 it is shown this trend depending on the ratio between phosphorus release and carbon uptake.

All this is translated in COD removal with a good performance for Tetrasphaera.

	day	%an_removal	%tot_remov	%an / %tot	An.C upt (C-mmol/l)	An.P rel (P-mmol/l)	P releas/C upt
25/02/2014	0	63.94	84.71	0.75	4.20	1.54	0.37
18/03/2014	21	74.92	86.79	0.86	5.18	1.25	0.24
01/04/2014	35	77.20	87.44	0.88	4.84	1.51	0.31
15/04/2014	49	74.08	86.29	0.86	4.87	1.23	0.25
29/04/2014	63	75.25	85.64	0.88	4.30	NA	NA
08/05/2014	72	65.96	75.49	0.87	3.17	2.03	0.64
13/05/2014	77	76.51	87.42	0.88	4.67	1.32	0.28
20/05/2014	84	66.00	84.54	0.78	3.99	NA	NA
27/05/2014	91	75.35	87.06	0.87	5.32	0.33	0.06
03/06/2014	98	78.88	85.87	0.92	5.71	0.62	0.11
24/06/2014	119	71.13	83.27	0.85	3.75	0.62	0.16
01/07/2014	126	80.12	85.63	0.94	5.67	NA	NA

Table 26. Tetrasphaera TOC results




Figure 63. Anaerobic Tetrasphaera activity in the whole analyzed period

VII (c). VSS and TSS

Samples for VSS and TSS analysis are taken at the end of the cycle in a 5 ml tube. The sample is stored in the fridge, then it is mixed as better as possible with a micropipette and filtered in a glass fiber according to the procedure described in paragraph V(b). *TSS and VSS*. The reactor works in continuous as described in paragraph IV. *Operation of the bioreactors*.

The results about total and volatile suspended solids show the biomass enrichment and the polyphosphate utilization, being:

$$\text{VSS} = \text{biomass} + \text{PHA} + \text{glycogen} = \text{weight}_{100} - \text{weight}_{550}$$

$$\text{TSS} = \text{VSS} + \text{polyphosphate} = \text{weight}_{100} - \text{weight}_{\text{filter}}$$

In the following graphs it can be observed that there is an initial increase of TSS and VSS for both the bioreactors throughout the analyzed period due to the acclimatization of the biomass and its enrichment. Then the TSS is in a range between 1.51 g/l and 4.20 g/l for the Acc. bioreactor and between 2.38 g/l and 4.75 g/l for Tet. bioreactor, whereas the VSS is between 1.00 g/l and 2.53 g/l for the Acc. bioreactor and between 2.11 g/l and 4.09 g/l for the Tet. bioreactor. The ratio VSS/TSS is generally quite high up to 0.87 for the first and 0.89 for the second one, due to the reason that a high amount of polyphosphate is accumulated and the phosphorus is successfully removed.

In the graph below it is shown the total suspended solids for Accumulibacter bioreactor, quite variable in the whole analyzed period. The volatile suspended solids are more concentrated around 1 and 2 g/l, as explained before.




Figure 64. TSS for Acc. in the whole analyzed period




Figure 65. VSS for Acc. in the whole analyzed period

Below are presented the graphs related to the Tetrasphaera bioreactor, with values of TSS and VSS much less spread compared to the Acc. one. In general, the biomass in the first bioreactor has been more constant in concentration all along the acclimatization period.




Figure 66. TSS for Tet in the whole analyzed period




Figure 67. VSS for Tet in the whole analyzed period

Finally, the ratio VSS/TSS is presented in the following graphs. This ratio is much more stable in the Tet. bioreactor.

A low VSS/TSS ratio suggests a better polyphosphate storage.




Figure 68. VSS/TSS for Acc. in the whole analyzed period




Figure 69. VSS/TSS for Tetrasphaera in the whole analyzed period

VII (d). Batch tests

Separate batch tests are performed moving the medium from the parent reactors working in continuous to a small reactor working in batch conditions. Some results from the N₂O sensors are reported here to show some examples. The test itself lasts 1 hour. The temperature is set at 20 °C and the pH at 7.1 for Tet. and 7.5 for Acc. Depending on the test, it is fed nitrate (test A), nitrite (test B) or nitrous oxide (test C, N₂O) in a pulse. See paragraph V(f). *Batch tests* for more details.




Figure 70. N₂O analysis for Accumulibacter test B (4th June 2014)

In this test it is fed 3.15 ml of NO_2^- . It can be seen that in each test N_2O is produced as soon as nitrite is fed. The graph above shows two different experiments with no signal in the middle. This is the typical trend of a N_2O reading sensor analysis, but in the following graphs are selected just some data to see the production rate. Data related to set up of the sensor are excluded.




Figure 71. N_2O analysis for Accumulibacter test B (4th June 2014), selected data




Figure 72. N_2O analysis for Accumulibacter test A (3rd June 2014)

In this test it is fed 3.15 ml of NO_3^- . The N_2O production rate is much lower than the previous test.




Figure 73. N_2O analysis for Tetrasphaera test A (4th July 2014)

Once again this is a test of type A, so it is fed 3.15 ml of NO_3^- . It can be seen a very fast N_2O production.




Figure 74. N_2O analysis for Tetrasphaera test B (6th July 2014)

This is a test of type B in which it is fed 3.15 ml of NO_2^- . The slopes are greater than the previous test so the N_2O production rate is faster.




Figure 75. N₂O analysis for Accumulibacter test C (5th June 2014)

In this test it is fed 8.25 ml of N₂O in three different pulses. It can be observed that it is consumed quite slowly because of the high amount fed into the bioreactor.

VII (e). FISH results

The biomass taken in the sampling is treated according to the procedure explained in the paragraph V(e). FISH. The samples are taken from the bioreactors working in continuous as described in the paragraph V. Analysis.

In the FISH analysis different probes are used to identify 4 types of Tetrasphaera microorganisms, 2 types of Accumulibacter, PAO mix that identifies both of them, GAOs (its probe is called GAO mix) and 1 probe is used to reveal all the rest of microorganisms (EUB mix).

In the following figures, are shown some images taken from the FISH analysis. The microscope is connected with a computer that can take these photographs. The predominant colours are yellow and green. The yellow indicates the microorganisms of interest in which the bioreactors should be enriched (Accumulibacter and Tetrasphaera), whereas the green shows the abundance of other microorganisms in the biomass.

This is a qualitative analysis, so the exact concentration of Accumulibacter and Tetrasphaera in the biomass is unknown.

The first image shows a quite large predominance of PAOs compared to the rest of microorganism population.




Figure 76. FISH image with EUB and PAO probes, March 2014

In the figure below, the zoom shows a particular of the Tetrasphaera reactor. Again it can be seen an enrichment in PAOs.




Figure 77. FISH image with EUB and TET-174 probe, March 2014

Another image showing the Tetrasphaera predominance. From this images it is clear there is a low abundance of other microorganisms.




Figure 78. FISH image with EUB and TET-266 probe, March 2014.

In this particular, the yellow colour shows the GAOs microorganisms. Again, the large predominance of other microorganisms different from GAOs is indicator of a very little presence of these microorganisms.




Figure 79. FISH image with EUB and GAO probes, February 2014

In this image, the filamentous represent a particular type of Tetrasphaera microorganisms, again present in the most part of the bioreactor.




Figure80. FISH image with EUB and TET-654 probe, March 2014

In the following figures it is shown a recent result showing Tetrasphaera predominance.




Figure 81. FISH image with EUB and TET-174-266-654 probes, July 2014

Below another figure using probes for PAOs.




Figure 82. FISH image with EUB and PAO probes, July 2014

CONCLUSIONS

The anaerobic activity of the bioreactors depends on the ratio phosphorus release / carbon uptake, increasing with it, whereas the de-nitrification activity decreases with decreasing the ratio between phosphorus and nitrate uptake.

The FISH analysis shows a general predominance of PAOs over GAOs and other microorganisms, for both the reactors. *Accumulibacter* or *Tetrasphaera* are the most abundant population in the two reactors being operated.

Nevertheless, the biomass in both cases does not perform a high level of phosphorus removal. Throughout the acclimatization study the Tet. bioreactor still in experimentation presents a net P removal up to about 20 %. Regarding the Acc. bioreactor the net P removal reaches values of 62 %. The nitrate removal is equal to 74 % for Acc. and 80 % for Tet. on average. The carbon removal for Tet is 84 % on average, whereas for Acc. is assumed equal to 100 % based on previous analysis performed on the same bioreactor.

The reason for the incomplete P removal is unknown, since both reactors were performing anaerobic P release and anoxic and aerobic P uptake. The factors influencing the P removal behaviour of *Tetrasphaera* require further study. While both organisms grow in EBPR systems with anaerobic/anoxic/aerobic configurations quite easily with great performance of enrichment in the reactor, the type of carbon source each organism uses is different and they contribute differently to P removal.

Regarding the production of nitrous oxides, just some examples are reported, since the sensors measuring their concentration are still at the beginning of their activity and the batch tests were started at the end of my experience. From these examples it can be seen that the production rate of N_2O is faster when it is fed nitrite than nitrate. In addition, in the example where it is fed N_2O , its consumption is quite fast, but slower than its production in the other examples. Some more analysis are needed to have a better idea about the production and consumption of nitrous oxides in this study.

Wastewater treatment has been a challenge along the time, due to variations in the chemical and physical characteristics of the influent and stringent effluent regulations. Activated sludge systems have been able to face all these changes. More recently, the technological development and the improvement of operation conditions have moved the attention to more efficient and cost-effective sequencing batch reactors (SBRs), providing better controls and results in wastewater treatment. This is coupled by the flexibility of SBR in the treatment of variable flows, option for anoxic or anaerobic conditions in the same tank, good oxygen contact with microorganisms and substrate and good removal efficiency.

Bibliography

Carvalho, G., Lemos, P. C., Oehmen, A., & Reis, M. A. (2007). Denitrifying phosphorus removal: linking the process performance with the microbial community structure. *Water research* , 4383 – 4396.

Foley, J., de Haas, D., Yuan, Z., & Lant, P. (2010). Nitrous oxide generation in full-scale biological nutrient removal wastewater treatment plants. *Water research* , 831 - 844.

Kampschreur, M. J., Temmink, H., Kleerebezem, R., Jetten, M. S., & van Loosdrecht, M. C. (2009). Nitrous oxide emission during wastewater treatment. *Water research* , 4093 - 4103.

López-Vázquez, C. M., Hooijmans, C. M., Brdjanovic, D., Gijzen, H. J., & van Loosdrecht, M. C. (2008). Factors affecting the microbial populations at full-scale enhanced biological phosphorus removal (EBPR) wastewater treatment plants in The Netherlands. *Water research* , 2349 – 2360.

Oehmen, A., Lemos, P. C., Carvalho, G., Yuan, Z., Keller, J., Blackall, L. L., et al. (2007). Advances in enhanced biological phosphorus removal: from micro to macro scale. *Water research* , 2271-2300.

Mohini Singh, R. K. Srivastava (2009). Sequencing batch reactor technology for biological wastewater treatment: a review. *Asia-Pacific journal of chemical engineering*.

Laboratory notes by Giuseppe Alessio Costa

<http://www.barnstablecountyhealth.org/ia-systems/information-center/compendium-of-information-on-alternative-onsite-septic-system-technology>

<http://water.worldbank.org/shw-resource-guide/infrastructure/menu-technical-options/wastewater-treatment>

<http://www.nyc.gov/html/dep/pdf/wssystem.pdf>

<http://www.brighthub.com/environment/science-environmental/articles/68537.aspx>

SAN+ analyzer user manual

The most images are photos taken in the laboratory during the activities

Appendix I. Accumulibacter TSS and VSS

Date	Day	TSS (g/l)	VSS (g/l)	VSS/TSS
29/01/2014	0	1.57	1.37	0.87
04/02/2014	6	1.51	1.28	0.85
13/02/2014	15	2.29	1.68	0.73
18/02/2014	20	2.67	1.77	0.66
25/02/2014	27	3.26	1.64	0.50
05/03/2014	35	2.99	1.79	0.60
11/03/2014	41	1.95	1.48	0.76
18/03/2014	48	2.76	2.02	0.73
25/03/2014	55	1.51	1.23	0.81
01/04/2014	62	4.20	2.53	0.60
15/04/2014	76	3.42	1.97	0.58
29/04/2014	90	3.24	1.30	0.40
13/05/2014	104	2.08	1.05	0.50
20/05/2014	111	1.76	1.00	0.57
27/05/2014	118	3.38	1.76	0.52
03/06/2014	125	2.42	1.43	0.59
19/06/2014	141	3.69	2.39	0.65
26/06/2014	148	1.51	1.02	0.68
01/07/2014	153	2.87	1.63	0.57

Date	Day	TSS (g/l)	VSS (g/l)	VSS/TSS
22/01/2014	0	2.38	2.11	0.89
28/01/2014	6	2.89	2.25	0.78
04/02/2014	13	4.07	3.07	0.76
13/02/2014	22	2.89	2.31	0.80
18/02/2014	27	2.80	2.24	0.80
25/02/2014	34	3.39	2.80	0.83
05/03/2014	42	2.56	2.18	0.85
11/03/2014	48	2.43	2.16	0.89
18/03/2014	55	3.43	2.81	0.82
25/03/2014	62	3.68	2.96	0.80
01/04/2014	69	3.52	2.93	0.83
08/04/2014	76	3.32	2.82	0.85
15/04/2014	83	3.04	2.50	0.82
29/04/2014	97	4.75	4.09	0.86
06/05/2014	104	3.40	2.89	0.85
13/05/2014	111	3.73	3.15	0.84
20/05/2014	118	3.39	2.76	0.81
27/05/2014	125	3.45	2.76	0.80
03/06/2014	132	3.34	2.65	0.79
11/06/2014	140	3.53	2.64	0.75
17/06/2014	146	3.53	2.86	0.81
26/06/2014	155	3.50	2.68	0.77
01/07/2014	160	3.74	2.80	0.75

***Appendix II. Tetrasphera
TSS and VSS***